

# ***QUICK START GUIDE***



Thank you for purchasing the **PE4** series engine control unit. The **PE4** is a compact and powerful system that handles all facets of fuel and ignition control. To get started quickly, please see below.

1. Find the CD or USB drive that came with your ECU or visit the PE website to download the correct version of **peMonitor** (<http://www.pe-ltd.com>, 'Downloads' page).
2. Install the **peMonitor** program on your laptop or PC by running the file `pe4MonitorInstaller_vX_XX_XX.exe`.
3. To install the free data viewer **peViewer**, run the file 'peViewerInstaller.msi'. This software allows the user to plot and manipulate data collected by the PE4 controller data acquisition system.
4. Once you have installed **peMonitor** on your machine, please refer to the 'Help' section to view the PE4 manual. In the manual, you will find instructions for connecting to the ECU, upgrading firmware and configuring the system.
5. Also included on PE website are 'Application Notes' that cover specific topics not covered in the manual.