



Firmware/Software Version:	PE3 V3.02.01 and higher
Relevant Hardware:	Basic 12-1 crank trigger wheel setup for 4-cylinder engine.
Additional Notes:	This configuration is equivalent to the old PE-ECU-1 system trigger wheel orientation.

Basic Trigger/Sync Setup



Trigger Wheel and Sensor are Shown in the Position of TDC for Cylinder #1

Define TDC Setup

